



iPhone 7 Plus Display Assembly Replacement

Prereq only for detaching the iPhone 7 Plus display assembly.

Written By: Paige Reisman




INTRODUCTION

Prereq only for detaching the display assembly.

TOOLS:

- [Spudger](#) (1)
 - [Suction Handle](#) (1)
 - [iFixit Opening Picks set of 6](#) (1)
 - [P2 Pentalobe Screwdriver iPhone](#) (1)
 - [iOpener](#) (1)
 - [Tri-point Y000 Screwdriver Bit](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Display Assembly




- Use the flat end of a spudger or a fingernail to disconnect the two lower display connectors by prying them straight up from their sockets on the logic board.
- ☑ To re-attach press connectors, press down on one end until it clicks into place, then repeat on the other end. Do not press down on the middle. If the connector is even slightly misaligned, the connector can bend, causing permanent damage.

Step 2




- Remove the three tri-point Y000 screws securing the bracket over the front panel sensor assembly connector:
 - One 1.3 mm screw
 - Two 1.0 mm screws
- Remove the bracket.

Step 3



- Disconnect the front panel sensor assembly connector from its socket on the logic board.
- ☑ This press connector should also be reconnected one end at a time to minimize the risk of bending.

Step 4



- Remove the display assembly.
- ☑ During reassembly, pause here if you wish to [replace the adhesive around the edges of the display](#).

To reassemble your device, follow these instructions in reverse order.

